3M

Digital Projector X45/SX55 **Quick Start Guide**

Thank you for purchasing this projector.


△WARNING ► Before using, read the "User's Manual - Safety Guide" and these manuals to ensure correct usage through understanding. After reading, store them in a safe place for future reference.

NOTE • The information in this manual is subject to chance without notice.

- The manufacture assumes no responsibility for any errors that may appear in this manual.
- The reproduction, transmission or use of this document or contents is not permitted without express written authority.

Contents of package

- (1) Projector
- (2) Remote control with two AA batteries
- (3) Power cord
- (4) RGB cable
- (5) Filter cover for bottom-up use
- (6) User's manuals
- (7) Soft case




NOTE • Keep the original packing materials for future reshipment. For moving the projector, be sure to use the original packing material. Use special caution for the lens part.

Arrangement

△WARNING ► Install the projector in a suitable environment according to the instructions in the "User's Manual - Safety Guide".

△CAUTION ► This projector has intake vents on the bottom. Avoid blocking these vents. Do not place objects near bottom of projector.



(calculated for a full size screen, ±10%)

(a) Screen size [inch (m)]	At 4:3 screen					At 16: 9 screen								
	(b) Projection distance [m (inch)]		(c) Screen height [cm (inch)]			(b) Projection distance [m (inch)]			(c) Screen height [cm (inch)]					
[IIIOII (III/]	min.	min. max.			up		min.		max.		down		up	
30 (0.8)	0.9 (35)	1.1 (42)	5 (2) 41	(16)	1.0	(38)	1.2	(46)	-1	(0)	39	(15)	
40 (1.0)	1.2 (47)	1.4 (56)	6 (2) 55	(22)	1.3	(52)	1.6	(62)	-2	(-1)	51	(20)	
50 (1.3)	1.5 (59)	1.8 (71)	8 (3) 69	(27)	1.6	(65)	2.0	(77)	-2	(-1)	64	(25)	
60 (1.5)	1.8 (72)	2.2 (85)	9 (4) 82	(32)	2.0	(78)	2.4	(93)	-2	(-1)	77	(30)	
70 (1.8)	2.1 (84)	2.5 (100)	11 (4) 96	(38)	2.3	(91)	2.8	(109)	-3	(-1)	90	(35)	
80 (2.0)	2.4 (96)	2.9 (114)	12 (5) 110	(43)	2.7	(105)	3.2	(125)	-3	(-1)	103	(41)	
90 (2.3)	2.7 (108)	3.3 (129)	14 (5) 123	(49)	3.0	(118)	3.6	(140)	-4	(-1)	116	(46)	
100 (2.5)	3.1 (120)	3.6 (143)	15 (6) 137	(54)	3.3	(131)	4.0	(156)	-4	(-2)	129	(51)	
120 (3.0)	3.7 (144)	4.4 (172)	18 (7) 165	(65)	4.0	(158)	4.8	(188)	-5	(-2)	154	(61)	
150 (3.8)	4.6 (181)	5.5 (216)	23 (9) 206	(81)	5.0	(197)	6.0	(235)	-6	(-2)	193	(76)	
200 (5.1)	6.1 (242)	7.3 (288)	30 (1	2) 274	(108)	6.7	(264)	8.0	(314)	-8	(-3)	257	(101)	
250 (6.4)	7.6 (303)	9.2 (361)	38 (1	5) 343	(135)	8.4	(330)	10.0	(393)	-10	(-4)	322	(127)	
300 (7.6)	9.2 (363)	11.0 (433)	46 (1	3) 411	(162)	10.1	(396)	12.0	(472)	-12	(-5)	386	(152)	

Adjusting the projector's elevation

△WARNING ► Do not adjust the projector's elevation during use or immediately after use. Handling the projector when it is hot (high temperature) could cause a burn and/or malfunction to the projector.

▲CAUTION ► If you press the elevation button without holding the projector, the projector might crash down, overturn, smash your fingers and possibly result in malfunction. To prevent damaging the projector and injuring yourself, always hold the projector whenever using the elevator buttons to adjust the elevator feet.

- ▶ Place the projector horizontally, except when using the elevator feet to adjust the height...
- After making sure that the projector has cooled adequately, press and hold in the elevator buttons while holding the projector. The elevator buttons and the elevator feet are on both sides.
 - on on


Elevator Elevator feet button

- 2. Raise or lower the projector to the desired height and release the elevator buttons.

 When you release the elevator buttons, the elevator fee
 - When you release the elevator buttons, the elevator feet will lock into position.
- 3 Finely adjust the height of the projector by twisting elevator feet by hand.


 About the filter cover for bottom up use
 - **►** For the projector installed bottom-up, use the accessory filter cover for bottom-up use. And in the case of a ceiling installation or the like, contact your dealer before installation.
 - ▶ Do not replace the filter cover during use or immediately after use. While the projector connects with a power supply, or the projector is in a high temperature state, handling could cause an electric shock, a fire, a burn and/or malfunction to the projector.Before handling, make sure the power switch is off and the power cord is not plugged in, then wait at least 45 minutes.
 - 1. After the projector has adequately cooled, slowly turn the projector so that the lens-side is facing up.


 Please be careful the projector doesnot fall. While the projector is placed lens-side up, hold the projector.
 - 2. Putting a finger on the filter cover's knob, slide the filter cover in the direction of the arrow to remove it.
 - 3. Replace the filter cover for bottom-up use and snap it back into place.
 - ▲ Slowly turn the projector so that the top is facing up.




Connecting your devices

Examples of connection with a computer







Connecting to a monitor (output)





Connecting to a speaker with amplifier (output)




Examples of connection with a VCR/DVD player










Connecting the power supply

△WARNING ► Please use extra caution when connecting the power cord as incorrect or faulty connections may result in fire and/or electrical shock.

- Only use the power cord that came with the projector. If it is damaged, contact your dealer to get a new one.
- Only plug the power cord into an outlet rated for use with the power cord's specified voltage range.
- Never modify the power cord. Never attempt to defeat the ground connection of the three-pronged plug.
- 1. Connect the connector of the power cord to the AC inlet of the projector.
- 2. Firmly plug the power cord plug into the outlet.




Putting batteries into the remote control

△WARNING ► Always handle the batteries with care and use them only as directed. Improper use may result in battery explosion, cracking or leakage, which could result in fire, injury and/or pollution of the surrounding environment.

- Be sure to use only the batteries specified. Do not use batteries of different types at the same time. Do not mix a new battery with used ones.
- Make sure the plus and minus terminals are correctly aligned when loading.
- Keep a battery away from children and pets.
- Do not recharge, short circuit, solder or disassemble a battery.
- Do not place a battery in a fire or water. Keep batteries in a dark, cool and dry play.
- If you observe leakage of a battery, wipe out the flower and then replace.

If the flower adheres to your body or clothes, rinse well with water immediately.

- 1 Remove the battery cover.
 - Slide back and remove the battery cover in the direction of the arrow.



- Align and insert the two AA batteries according to their plus and minus terminals as indicated in the remote control.
- Close the battery cover.
 Replace the battery cover in the direction of the arrow and snap it back into place.








Operating

△WARNING ► When the power is on, a strong light is emitted. Do not look into the lens or vents of the projector.


Turning on the power


- Set the power switch to the ON position.
- Press the STANDBY/ON (projector or remote control) button.



Displaying

- To select an input signal, use the button of INPUT (projector), or the buttons of RGB, VIDEO or SEARCH (remote control).
- 2. To change the aspect ratio, use the button Zoom knob ASPECT (remote control). Focus ring
- 3. To adjust the zoom and focus, use the zoom knob and the focus ring.






Turning off the power

- Press the STANDBY/ON (projector or remote control) button. The message "Power off?" will appear on the screen for approximately 5 seconds.
- Press the STANDBY/ON (projector or remote control) button again while the message is visible.

The projector lamp will go off, and the POWER indicator will begin blinking orange. Then the POWER indicator will stop blinking and light to solid orange when the lamp cooling is complete.

Make sure that the power indicator lights to solid orange, set the power switch to the OFF position. The POWER indicator will go off.



Lamp

⚠ WARNING







A HIGH PRESSURE

▶ The projector uses a high-pressure mercury glass lamp. The lamp can break with a loud bang, or burn out, if jolted or scratched, handled while hot, or worn over time. Note that each lamp has a different lifetime, and some may burst or burn out soon after you start using them. In addition, when the bulb bursts, it is possible for shards of glass to fly into the lamp housing, and for gas containing mercury to escape from the projector's vent holes.

▶ About disposal of a lamp • This product contains a mercury lamp; do not put in trash. Dispose of in accord with environmental laws.

For lamp recycling, go to www.lamprecycle.org. (in the US)

For product disposal, contact your local government agency or www.eiae.org (in the US) or www.epsc.ca (in Canada).

For more information, call your dealer.



• If the lamp should break (it will make a loud bang when it does), unplug the power cord from the outlet, and make sure to request a replacement lamp from your local dealer. Note that shards of glass could damage the projector's internals, or cause injury during handling, so please do not try to clean the projector or replace the lamp yourself.

the plug from the power outlet

- Disconnect If the lamp should break (it will make a loud bang when it does), ventilate the room well, and make sure not to breathe the gas that comes out of the projector vents, or get it in your eyes or mouth.
 - Before replacing the lamp, turn the projector off and unplug the power cord, then wait at least 45 minutes for the lamp to cool sufficiently. Handling the lamp while hot can cause burns, as well as damaging the lamp.
 - Never unscrew except the appointed (marked by an arrow) screws.



- Do not open the lamp cover while the projector is suspended from above. This is dangerous, since if the lamp's bulb has broken, the shards will fall out when the cover is opened. In addition, working in high places is dangerous, so ask your local dealer to have the lamp replaced even if the bulb is not broken.
- Do not use the projector with the lamp cover removed. At the lamp replacing, make sure that the screws are screwed in firmly. Loose screws could result in damage or injury.
- Use only the lamp of the specified type.
- If the lamp breaks soon after the first time it is used, it is possible that there are electrical problems elsewhere besides the lamp. If this happens, contact your local dealer or a service representative.




- Handle with care: jolting or scratching could cause the lamp bulb to burst during use.
- If the indicators or a message prompts you to replace the lamp (see the "User's Manual - Operating Guide"), replace the lamp as soon as possible. Using the lamp for long periods of time, or past the replacement date, could cause it to burst. Do not use old (used) lamps; this is a cause of breakage.


When the indicators or a message prompts you to replace the lamp, replace the lamp as soon as possible.

- 1 Turn the projector off, and unplug the power cord. Allow the lamp to cool for at least 45 minutes.
- 2. To order a new lamp, contact your dealer. Lamp number 78-xxxx-xxxx-x If the projector is mounted on the ceiling, or if the lamp has broken, also ask the dealer to replace the lamp.

In the case of replacement by yourself,

- After making sure that the projector has cooled adequately, slowly turn over the projector, so that the bottom is facing up.
- 4. Please unhook the claws of the lamp cover using a minus screwdriver or similar, and remove the lamp cover.
- 5. Loosen the 2 screws (marked by arrow) of the lamp, and slowly pick up the lamp by the handles.
- 6. Insert the new lamp, and retighten firmly two screws that are loosened in the previous process to lock it in place.
- 7. Interlocking the 2 tabs of the lamp cover to the projector, position the lamp cover on the projector. Then push the center point of two claws to fix the lamp cover.
- 8. Slowly turn the projector so that the top is facing up.
- 9. Turn the projector on, and reset the lamp time using the LAMP TIME function of OPTION menu.





NOTE • When the lamp has been replaced after the message of "THE POWER WILL TURN OFF AFTER 0hr." is displayed, complete the following operation within 10 minutes of switching power on.

 Incorrectly resetting of the lamp timer (resetting without replacement, or neglect of resetting after replacement) will result in incorrect message functions.

Air filter

△WARNING ► Before caring, make sure the power switch is off and the power cable is not plugged in, then allow the projector to cool sufficiently. The care in a high temperature state of the projector could cause a burn and/or malfunction to the projector.

- ▶ Use only the air filter of the specified type. Do not use the projector with the air filter and filter cover removed.
- ► Avoid wetting the projector or inserting liquids in the projector. It could result in a fire, an electric shock, and and/or malfunction to the projector.

△CAUTION ► Please replace the air filter when it is damaged or too soiled, and also when you replace the lamp.

When the indicators or a message prompts you to clean the air filter, clean the air filter as soon as possible. If the air filter becomes clogged by dust or the like, internal temperatures rise and the power may be automatically turned off for malfunction prevention.

- 1. Turn the projector off, and unplug the power cord. Allow the projector to cool for at least 45 minutes. And prepare a vacuum cleaner.
- 2. After making sure that the projector is cool adequately, slowly turn the projector so that the lens-side is facing up. Please be careful for a projector not to fall. While the projector is placed lens-side up, hold the projector.
- 3. Putting a finger on the filter cover's knob, slide the filter cover in the direction of the arrow to remove it.
- 4 Holding the air filter's knob, pull the air filter off.
- 5. Apply a vacuum cleaner to the vent of the projector for the air filter. And then slowly turn the projector bottom up.
- 6. Apply a vacuum cleaner to the air filter and filter cover. Please replace the air filter when it is damaged or too soiled.

To order a new air filter, contact your dealer and tell the air

filter type number = 78-xxxx-xxxx-x.

An air filter of specified type will come even with the replacement lamp for this projector.

- 7. Position the cleaned air filter or a new air filter into place, and push the points of "PUSH" word with claws to fix the air filter.
- Replace the filter cover and snap it back into place.
- Slowly turn the projector so that the top is facing up.
- 10. Turn the projector on, and reset the filter time using the FILTER TIME function of OPTION menu.

NOTE • Incorrectly resetting of the filter timer (resetting without replacement, or neglect of resetting after replacement) will result in incorrect message functions.



Filter cover's knob

Filter cover



Air filter